


# INSTALLATION GUIDE



## **N5-RA60-4 Shelving (ALUMINUM)**

Transit High Roof & Medium Roof

Promaster Standard Roof & High Roof

Nissan NV High Roof

Box Truck / Trailer

Sprinter RWB, LWB, XWB



# QUICK START GUIDE


## Phase 1 - Assembly

❑ 1.1 Setup.....	3 - 4
❑ 1.2 Shelf Assembly.....	5

## Phase 2 - Installation

❑ 2.1 Attach Wall Brackets To The End Panels.....	6
❑ 2.2 Mark Holes For Plus Nuts.....	7
❑ 2.3 Attach Plus Nut.....	8 - 9
❑ 2.4 Attach Shelf Unit To the Floor.....	10 - 11
❑ 2.5 Attach Wall Brackets.....	12 - 13

# REQUIRED ITEMS




**2  
PERSONS**

- ❑ Cordless Impact
- ❑ Cordless Drill
- ❑ Tape Measure
- ❑ Marker
- ❑ 1/2" Socket
- ❑ 1/2" Drill Bit w/ Drill Collar ( Set at 1/2" )
- ❑ 3/8" Driver Bit
- ❑ Knife
- ❑ Plusnut Tool / Plusnut Gun ( 5/16" )

# PHASE 1 – ASSEMBLY

## 1.1 SETUP

1.1.1 Unpack components; compare with the bill of materials.




1.1.2 Verify all parts are present.

### BILL OF MATERIALS

Item No.	Description	Qty.
40 - 750	Bracket, N5 Series, Right	1
40 - 751	Bracket, N5 Series, Left	1
84-012	Foldaway bracket - middle	2
40 - 705	End Panel ( Left )	1
40 - 706	End Panel ( Right )	1
60 - 11.875 x 60	Shelf Tray, Black Plywood, Usable 12" x 60"	1
60 - 13.875 x 60	Shelf Tray, Black Plywood, Usable 14" x 60"	3
94 - 4025	Assembly Fastener Kit	1
96 - 4025	Install Fastener Kit	1

1.1.3 Fastener kits.


94 - 4025 Fastener Kit





Fastener Assembly

- 8x  # 90-204 Hex Bolt 5/16"-18 x 3/4" GR-5 ZINC
- 32x  # 92-102 Screw HWH #14 x 1" ZINC
- 8x  # 94-116 Serrated Nut 5/16"-18 ZINC
- 8x  # 98-116 Flat Washer 5/16" - 18 x 1" ZINC


8x

 #90-204 Hex Bolt 5/16" x 3/4"

 #98-116 Flat Washer

 #94-116 Serrated Nut







32x

 #92-102 Screw #14 x 1"


96 - 4025 Fastener Kit





Fastener Assembly


- 4x  # 90-011 Hex Bolt 5/16"-18 x 1-3/4" GR-5 ZINC
- 8x  # 90-212 Hex Bolt 5/16"-18 x 1-1/4" GR-5 ZINC
- 12x  # 94-132 Plusnut
- 12x  # 98-116 Flat Washer 5/16", O.D. 7/8" ZINC
- 12x  # 98-122 Lock Washer 5/16" ZINC
- 4x  # 98-157 Spacer 0.375" ID, x 1.0" OD x 0.25" LONG NYLON

8x


 #90-212 Hex Bolt 5/16" x 1-1/4"


 #98-122 Lock Washer


 #98-116 Flat Washer


 #94-132 5/16" Plusnut


4x

 #90-011 Hex Bolt 5/16" x 1-3/4"

 #98-122 Lock Washer

 #98-116 Flat Washer

 #98-157 Spacers ( QTY = GAP BETWEEN FLOOR AND END PANEL )

 #94-132 5/16" Plusnut



# PHASE 1 – ASSEMBLY

## 1.2 SHELF ASSEMBLY

1.2.1 Attach both panels to the shelf trays.

**NOTE:** You can adjust the bottom shelf location to maximize or minimize your space over the wheel.

**TIPS:** Shelf tray position guide.



### TOOLS

- Cordless Impact
- 3/8" Driver Bit

### HARDWARE USED

32x





#92-102 Screw #14 x 1"

# PHASE 2 – INSTALLATION

## 2.1 ATTACH WALL BRACKETS TO THE END PANELS

**IMPORTANT:** For all **Box Trucks**, make sure that the shelving is securely fastened to the structure of the truck.

- 2.1.1**
- Lift the assembled shelf to the vehicle, then put it in place.
  - Attach the brackets to the panels aligning the brackets to the horizontal rim of the vehicle.



Attach the brackets to the panels aligning the brackets to the horizontal rim of the vehicle.

### TOOLS

- ❑ Cordless Impact
- ❑ 1/2" Socket

### HARDWARE USED

**8x** HAND-TIGHTEN THE BOLTS



#90-204 Hex Bolt 5/16" x 3/4"



#98-116 Flat Washer





#94-116 Serrated Nut



# PHASE 2 – INSTALLATION

## 2.2 MARK HOLES FOR PLUS NUTS

**2.2.1** After attaching the brackets mark the holes on the brackets and end panels to the vehicle.





Mark 8 holes of the brackets on the vehicle as shown on the image.

**NOTE:** If you are using Ranger wall kits, please go to **PAGE 13**.

### TOOLS

☐ Marker

MARK



Mark 2 holes of each end panel on the vehicle floor.

**NOTE:** If you are using Ranger floor, please go to **PAGE 11**.

### TOOLS

☐ Marker

MARK





# PHASE 2 – INSTALLATION

## 2.3 ATTACH PLUS NUTS

- 2.3.1**
- Lift the assembled shelf on the side.
  - Drill all the marks using 1/2" drill bit w/ drill collar, then attach plus nuts to the holes.

**NOTE:** Use 1/2" drill bit with drill collar to stop drill at 1/2" depth.

**WARNING:** Before drilling, ensure that you will not hit any critical parts of the vehicle like the **Gas tank**, **Wiring Harness** and **Hose**.



PLUSNUT

Drill all the marks then, attach plus nuts to the holes.

### TOOLS


- ☐ Cordless Drill
- ☐ 1/2" Drill Bit w/ Drill Collar ( Set at 1/2" )
- ☐ Plus Nut Tool ( 5/16" )

### HARDWARE USED

**12x**



#94-132 Plus Nut




DRILL COLLAR  
( SET AT 1/2" )




### 2.3.2 How to attach plus nut.

#### • USING PLUSNUT GUN

**STEP:** Put the plusnut on the plusnut gun, then attach the plus nut in the hole by turning the gun forward until the plus nut locks, then remove the gun by turning in reverse.



**FORWARD**




**REVERSE**



#### • USING THE 6491 PLUSNUT TOOL

**NOTE:** The hardware used for the 6490 plusnut tool is not included in the fastener bag.  
The 6490 plusnut tool can be ordered separately upon demand at no charge.

**6491**



#### **HARDWARE USED**

-  Flat washer 5/16"
-  Flat washer 5/16" BS x 7/8" OD

#### **TOOLS**

- ☐ Cordless Impact
- ☐ 1/2" Socket
- ☐ 9/16" Wrench


#### **STEP 1:**

Assemble the 6491 plusnut tool with the hardware needed, plus nut and the 9/16" wrench as shown.



#### **STEP 2:**

Attach the plus nut in the hole by turning the bolt forward using an impact with a 1/2" socket until the plusnut locks, then remove the bolt by turning the impact in reverse.



**FORWARD**





**REVERSE**

# PHASE 2 – INSTALLATION

## 2.4 ATTACH SHELF UNIT TO THE FLOOR

### WITHOUT RANGER FLOOR

**2.4.1** Put the assembled shelf back in place aligning the holes to the plusnuts, then install the end panels to the plus nuts.



#### TOOLS

- ☐ Cordless Impact
- ☐ 1/2" Socket

#### HARDWARE USED

**6x**



#90-011 Hex Bolt 5/16" x 1-3/4"



#98-122 Lock Washer



#98-116 Flat Washer




#98-157 Spacers

( QTY = GAP BETWEEN FLOOR AND END PANEL )



#94-132 5/16" Plusnut

MOST VEHICLE USE 1 SPACER WHEN NOT OVER RIBS




W/ Spacer


W/O Spacer

## WITH RANGER FLOOR

- 2.4.2**
- Lift the shelving unit inside the van, then put it in place.
  - Install the shelving unit to the floor mounting track by sliding bolts in the mounting tracks, and putting screw in the last rear slot of the end panels of the shelving unit.



### STANDARD FLOOR



#### TOOLS

- ☐ Cordless Impact
- ☐ 3/8" Driver Bit
- ☐ 1/2" Socket

#### HARDWARE USED

**2x** FLOOR FASTENER KIT



#92-102 Screw 1"

#### HARDWARE USED

**2x** FLOOR FASTENER KIT



#90-490 Carriage Bolt 5/16" x 1"




#98-122 Flat Washer



#98-116 Lock Washer



#94-104 Hex Nut



### E-FLOOR

#### TOOLS

- ☐ Marker
- ☐ 7/16" Drill Bit
- ☐ 1/2" Socket
- ☐ Drill Collar

7/16 drill hole

#### HARDWARE USED

**4x** HAND-TIGHTEN THE BOLTS

#### HARDWARE USED

**4x** HAND-TIGHTEN THE BOLTS



#90-204 Hex Bolt 5/16" x 3/4"



#98-116 Lock Washer



#98-116 Flat Washer



#99-114 Zinc Alloy Tapping Inserts for Softwood



# PHASE 2 – INSTALLATION



## 2.5 ATTACH WALL BRACKETS

### WITHOUT RANGER WALL KITS

**2.5.1** Aligned the wall brackets to the plus nuts, then install the wall brackets to the wall.

**NOTE:** Tightened the bolts that used to attached the wall bracket to the wall or wall kits 1<sup>st</sup> before the bolts that used to attached the wall bracket to the end panel.

**IMPORTANT:** After installation is completed, ensure all bolts are tightened.



#### TOOLS

- Cordless Impact
- 1/2" Socket

#### HARDWARE USED

8x




#90-212 Hex Bolt 5/16" x 1-1/4"

#98-122 Lock Washer

#98-116 Flat Washer



#94-132 5/16" Plusnut



## WITH RANGER WALL KITS

**2.5.2** First align the wall brackets to the wall mounting track kits, then install the wall brackets to the wall mounting track kits using channel nuts.

**IMPORTANT:** First tighten the bolts that secure the wall bracket to the wall or wall kits, and then tighten the bolts that secure wall bracket to the end panels. After installation is completed, ensure all bolts are properly tightened.




### TOOLS

- ☐ Cordless Impact
- ☐ 1/2" Socket

### FASTENERS USED

**8x** WALL KITS FASTENER KIT




#90-208 Hex Bolt 5/16" x 1"

#98-122 Lock Washer

#98-116 Flat Washer

#94-150 Channel Nut





**“You have successfully installed your  
N5-RA60-4**

**Thank you for doing business with us.”**

For any feedback or suggestions you may have, please contact: [cs@rangerdesign.com](mailto:cs@rangerdesign.com)

